



MAXTRAC SUSPENSION
4030 E LEAVERTON CT
ANAHEIM, CA 92807
877-929-3016
WWW.MAXTRACSUSPENSION.COM
SALES@MAXTRACSUSPENSION.COM

**PRODUCT: 833720 - COIL SPRING SPACERS
05-12 FORD F250 / F350 4WD**

PARTS LIST QTY

COIL SPACER	2
M14-2.0 X 100 BOLT	2
M14 FLAT WASHER	2

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAXTRAC IMMEDIATELY 877-929-3016

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

PRIOR TO INSTALLATION:

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.

INSTALLATION INSTRUCTIONS - 833720

1. Unbolt the brake line bracket from the coil retainer.
2. Remove guide clip for the hub vacuum line.
3. Unbolt the sway bar end links from the sway bar



4. Disconnect the shock from the coil bucket.
5. Lower the axle, remove the coil spring, and unbolt lower coil retainer from the axle.
6. Place the new Maxtrac spacer between the axle and lower coil retainer. Tighten using provided hardware.



7. Jack axle up so that the coil spring is seated, then reattach shock to the coil bucket.
8. Reattach the sway bar end links.
9. Reattach brake line bracket and vacuum line.

