



MAXTRAC SUSPENSION
4030 E. LEAVERTON CT
ANAHEIM, CA 92807
714-630-0363
WWW.MAXTRACSUSPENSION.COM
SALES@MAXTRACSUSPENSION.COM

PRODUCT: 836530
99-06 TOYOTA TUNDRA LEVELING KIT, 3.0"

PARTS LIST QTY

PARTS LIST	QTY
STRUT SPACER	2
10mm X 1.25 FLANGE NUT	6

Please double check the parts list before beginning the installation, to ensure all parts are present. If parts are missing, please contact Maxtrac Suspension immediately, 714-630-0363. Read the instructions thoroughly before installation.

PRIOR TO INSTALLATION:

1. Factory service manual is recommended to have on hand.
2. Make sure that all parts in the parts list are present, and do not start the installation without a full set of parts.
3. Secure and properly block vehicle prior to beginning installation
4. Always wear safety glasses when using power tools or working under the vehicle
5. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW TIRES. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER THE VEHICLE'S RIDE HEIGHT IS ALTERED.

INSTALLATION STEPS

1. Remove the four bolts on the lower ball joint, and the sway bar nuts on both sides of the truck, allowing the lower control arm to drop to its lowest point.
2. Remove the upper strut mount nuts.
3. Remove the strut from the vehicle and mount it in a bench vise, and install the Maxtrac kit. Torque fasteners to OEM specs, the strut will be rotated 180 degrees when reinstalled.
4. Repeat steps 1 and 2 on the passenger side of the vehicle. Reinstall the sway bar nuts on both sides after the upper ball joints have been reattached.
5. After 50 miles of driving, re-torque all hardware.
6. Perform Alignment.

