



MAXTRAC SUSPENSION  
4030 E LEAVERTON CT  
ANAHEIM, CA 92807  
714-630-0363

[WWW.MAXTRACSUSPENSION.COM](http://WWW.MAXTRACSUSPENSION.COM)  
[SALES@MAXTRACSUSPENSION.COM](mailto:SALES@MAXTRACSUSPENSION.COM)

**PRODUCT: 839715 - COIL SPRING SPACER 1.5"**  
**07-12 JEEP JK 1.5" LEVELING KIT**

**PARTS LIST**

**QTY**

FRONT SPRING SPACERS	2
FLATWASHER, 7/16	4
NYLOCK NUT, 7/16-14	2
HEX CAP SCREW, 7/16-14X1-1/4	2

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION, TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING, PLEASE CONTACT MAXTRAC IMMEDIATELY 714-630-0363

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE BEGINNING THE INSTALLATION.

**PRIOR TO INSTALLATION:**

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING NEW SUSPENSION PARTS. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**

1. Raise front of Jeep, support frame with jack stands, and remove wheels & tires.



2. Remove bolt that holds brake lines to the frame, both sides.



3. Remove lower shock bolts



4. Remove Sway bar bolts from the frame.



5. Remove Coil Springs and isolator.



7. Install new Maxtrac Spacer, with bolt, nut, and washer. Install Rubber isolator.



8. Reinstall coil springs after rubber isolator is back in place.

9. Reconnect sway bar to the frame (#4)

10. Reconnect the shocks.

11. Reconnect the brake line tab, holding the brake line, to the frame (#2)

Install wheels and tires, then set the Jeep on the ground. It's important to re-check the tightness of all hardware. Make sure that the steering wheel is straight. Drive to an alignment shop and have alignment set to factory specs.